



INDUSTRIAL FITTINGS - fittings, connectors


Brass connectors - RV type


Material: Brass
Working temp.: From -10°C up to +100°C


90° elbow BSP female		
		
		3400
code	size	thread size [inch]
RV-3400-04	8	1/4
RV-3400-06	10	3/8
RV-3400-08	15	1/2
RV-3400-12	20	3/4
RV-3400-16	25	1
RV-3400-20	32	1.1/4
RV-3400-24	40	1.1/2
RV-3400-32	50	2

90° elbow BSP female / male		
		
		3401
code	size	thread size [inch]
RV-3401-04	8	1/4
RV-3401-06	10	3/8
RV-3401-08	15	1/2
RV-3401-12	20	3/4
RV-3401-16	25	1
RV-3401-20	32	1.1/4
RV-3401-24	40	1.1/2
RV-3401-32	50	2

Adapter BSP female		
		
		3410
code	size	thread size [inch]
RV-3410-04	8	1/4
RV-3410-06	10	3/8
RV-3410-08	15	1/2
RV-3410-12	20	3/4
RV-3410-16	25	1
RV-3410-20	32	1.1/4
RV-3410-24	40	1.1/2
RV-3410-32	50	2


Tee connection BSP female		
		
		3420
code	size	thread size [inch]
RV-3420-04	8	1/4
RV-3420-06	10	3/8
RV-3420-08	15	1/2
RV-3420-12	20	3/4
RV-3420-16	25	1
RV-3420-20	32	1.1/4
RV-3420-24	40	1.1/2
RV-3420-32	50	2


Nipple BSP male		
		
		3430
code	size	thread size [inch]
RV-3430-04	8	1/4
RV-3430-06	10	3/8
RV-3430-08	15	1/2
RV-3430-12	20	3/4
RV-3430-16	25	1
RV-3430-20	32	1.1/4
RV-3430-24	40	1.1/2
RV-3430-32	50	2


Reduction nipple BSP male			
			
		3430	
code	size	thread size [inch]	thread size [inch]
RV-3430-04-06	8	1/4	3/8
RV-3430-06-08	10	3/8	1/2
RV-3430-08-12	15	1/2	3/4
RV-3430-12-16	20	3/4	1
RV-3430-16-20	25	1	1.1/4
RV-3430-20-24	32	1.1/4	1.1/2
RV-3430-24-32	40	1.1/2	2
RV-3430-32-40	50	2	2.1/2


INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - RV type

Blank plug BSP male		
		
3480		
code	size	thread size [inch]
RV-3480-04	8	1/4
RV-3480-06	10	3/8
RV-3480-08	15	1/2
RV-3480-12	20	3/4
RV-3480-16	25	1
RV-3480-20	32	1.1/4
RV-3480-24	40	1.1/2
RV-3480-32	50	2

Blank cap BSP female		
		
3490		
code	size	thread size [inch]
RV-3490-04	8	1/4
RV-3490-06	10	3/8
RV-3490-08	15	1/2
RV-3490-12	20	3/4
RV-3490-16	25	1
RV-3490-20	32	1.1/4
RV-3490-24	40	1.1/2
RV-3490-32	50	2

Reduction adapter BSP male / female			
			
3450			
code	size	male thread size [inch]	female thread size [inch]
RV-3450-04-02	6	1/4	1/8
RV-3450-06-02	6	3/8	1/8
RV-3450-06-04	8	3/8	1/4
RV-3450-08-04	8	1/2	1/4
RV-3450-08-06	10	1/2	3/8
RV-3450-12-04	8	3/4	1/4
RV-3450-12-06	10	3/4	3/8
RV-3450-12-08	15	3/4	1/2
RV-3450-16-06	10	1	3/8
RV-3450-16-08	15	1	1/2
RV-3450-16-12	20	1	3/4
RV-3450-20-12	20	1.1/4	3/4
RV-3450-20-16	25	1.1/4	1
RV-3450-24-12	20	1.1/2	3/4
RV-3450-24-16	25	1.1/2	1
RV-3450-24-20	32	1.1/2	1.1/4
RV-3450-32-20	32	2	1.1/4
RV-3450-32-24	40	2	1.1/2
RV-3450-40-32	50	2.1/2	2

Pipe joint BSP female		
		
3460		
code	size	thread size [inch]
RV-3460-08	15	1/2
RV-3460-12	20	3/4
RV-3460-16	25	1

INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - MU type

Working press::Up to 12 bar

Working temp.:From -20°C up to +100°C

Nipple BSP male (internal cone)



code	thread size [inch]	thread size [inch]	spanner size [mm]
MU-4201	1/8	1/8	14
MU-4202	1/8	1/4	17
MU-4203	1/4	1/4	17
MU-4204	1/4	3/8	19
MU-4208	1/4	1/2	24
MU-4205	3/8	3/8	19
MU-4206	3/8	1/2	24
MU-4213	3/8	3/4	32
MU-4207	1/2	1/2	24
MU-4209	1/2	3/4	32
MU-4215	1/2	1	36
MU-4211	3/4	3/4	32
MU-4210	3/4	1	36
MU-4216	1	1	36

Reduction adapter BSP female / male



code	thread size [inch]	thread size [inch]	spanner size [mm]
MU-4251	1/4	1/8	17
MU-4256	3/8	1/8	19
MU-4252	3/8	1/4	19
MU-4257	1/2	1/8	24
MU-4254	1/2	1/4	24
MU-4253	1/2	3/8	21
MU-4258	3/4	3/8	32
MU-4255	3/4	1/2	32
MU-4259	1	1/2	36
MU-4260	1	3/4	36

90° elbow BSP female



code	thread size [inch]
MU-1142	1/8
MU-1143	1/4
MU-1144	3/8
MU-1145	1/2
MU-1146	3/4
MU-1147	1

"T" Tee connection BSP female



code	thread size [inch]
MU-1172	1/8
MU-1173	1/4
MU-1174	3/8
MU-1175	1/2
MU-1176	3/4
MU-1177	1

"Y" Tee connection BSP female



code	thread size [inch]
MU-1190	3/8
MU-1191	1/2

Cross BSP female





code	thread size [inch]
MU-1195	3/8
MU-1198	1/2


* - versions with EUROSTANDARD DN 5, DN7.2 couplers available as well


INDUSTRIAL FITTINGS - fittings, connectors


Brass connectors - MU type

Hose fitting, BSP male, 37° internal cone			
			
code	thread size [inch]	hose I.D. [mm]	spanner size [mm]
MU-2850	1/8	6	14
MU-2866	1/8	8	14
MU-2851	1/8	9	14
MU-2867	1/4	4	17
MU-2852	1/4	6	17
MU-2861	1/4	8	17
MU-2853	1/4	9	17
MU-2854	1/4	13	17
MU-2855	3/8	6	19
MU-2868	3/8	8	19
MU-2856	3/8	9	19
MU-2857	3/8	13	19
MU-2858	1/2	6	24
MU-2859	1/2	9	24
MU-2860	1/2	13	24
MU-2869	3/4	13	32
MU-2863	3/4	19	32
MU-2864	1	25	36

Hose fitting, ball end (insert)		
		
code	nut size [inch]	hose I.D. [mm]
MU-2891	1/4 (MU-2881)	6
MU-2893	1/4 (MU-2287)	9
MU-2895	3/8 (MU-2883)	6
MU-2896	3/8 (MU-2883)	9
MU-2897	1/2 (MU-2885)	6
MU-2898	1/2 (MU-2885)	9
MU-2899	1/2 (MU-2885)	13

Hexagonal nut			
			
code	thread size [inch]	hole diameter [mm]	spanner size [mm]
MU-2881	1/4	9.6	17
MU-2887	1/4	10.4	17
MU-2883	3/8	12.6	19
MU-2885	1/2	15.2	24

BSP female adaptor		
		
code	thread size [inch]	spanner size [mm]
MU-4221	1/4	17
MU-4222	3/8	22
MU-4223	1/2	27
MU-4224	3/4	32

Hose connector		
		
code	hose I.D. [mm]	length [mm]
EW-MS-11300	4	64
EW-MS-11301	6	72
EW-MS-11302	6	72
EW-MS-11303	9	72
EW-MS-11304	13	72

INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - EW type

Working press.: Up to 40 bar

Working temp.: From -10°C up to +90°C

Hose fitting, BSP female, fixed nut



code	thread size [inch]	hose I.D. [mm]	spanner size [mm]
EW-MS-11309	1/8	4	12
EW-MS-11310	1/8	6	12
EW-MS-13311	1/8	9	14
EW-MS-11312	1/4	4	17
EW-MS-11313	1/4	6	17
EW-MS-11314	1/4	9	17
EW-MS-11315	1/4	13	17
EW-MS-11316	3/8	6	19
EW-MS-11317	3/8	9	19
EW-MS-11318	3/8	13	19
EW-MS-11319	1/2	6	24
EW-MS-11320	1/2	9	24
EW-MS-11321	1/2	13	24
EW-MS-11322	3/4	9	32
EW-MS-11323	3/4	13	32
EW-MS-11324	3/4	19	32
EW-MS-11331	1	19	36
EW-MS-11332	1	25	36
EW-MS-11333	1	32	36

Hose fitting, BSP female, swivel nut



code	thread size [inch]	hose I.D. [mm]	spanner size [mm]
EW-MS-K-02-04	1/8	4	12
EW-MS-K-02-06	1/8	6	12
EW-MS-K-04-04	1/4	4	17
EW-MS-K-04-06	1/4	6	17
EW-MS-K-04-09	1/4	9	17
EW-MS-K-06-04	3/8	4	19
EW-MS-K-06-06	3/8	6	19
EW-MS-K-06-09	3/8	9	19
EW-MS-K-08-06	1/2	6	24
EW-MS-K-08-09	1/2	9	24
EW-MS-K-08-13	1/2	13	24

Hose fitting with ball end (insert)



code	nut size [inch]	hose I.D. [mm]
EW-MS-W-02-04	1/8	4
EW-MS-W-02-06	1/8	6
EW-MS-W-04-04	1/4	4
EW-MS-W-04-06	1/4	6
EW-MS-W-04-09	1/4	9
EW-MS-W-06-04	3/8	4
EW-MS-W-06-06	3/8	6
EW-MS-W-06-09	3/8	9
EW-MS-W-08-06	1/2	6
EW-MS-W-08-09	1/2	9
EW-MS-W-08-13	1/2	13

Hose fitting, BSP male, 45° internal cone



code	thread size [inch]	hose I.D. [mm]	spanner size [mm]
EW-MS-11341	1/8	4	14
EW-MS-11351	1/8	6	14
EW-MS-13352	1/8	9	14
EW-MS-11368	1/4	4	17
EW-MS-11331A	1/4	6	17
EW-MS-11340A	1/4	9	17
EW-MS-11371	1/4	13	17
EW-MS-11332A	3/8	6	17
EW-MS-11334A	3/8	9	17
EW-MS-11343	3/8	13	19
EW-MS-11367	1/2	6	24
EW-MS-11366	1/2	9	24
EW-MS-11344	1/2	13	24
EW-MS-11325	3/4	9	32
EW-MS-11326	3/4	13	32
EW-MS-11327	3/4	19	32
EW-MS-11328	1	19	36
EW-MS-11329	1	25	36
EW-MS-11330	1	32	36

Hexagonal nut



code	thread size [inch]	spanner size [mm]
EW-MS-N-02	1/8	12
EW-MS-N-04	1/4	17
EW-MS-N-06	3/8	19
EW-MS-N-06LH	3/8 (left thread)	19
EW-MS-N-08	1/2	24

INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - EW type

Working press.: Up to 63 bar

Working temp.: From -10°C up to +90°C

90°elbow, BSP male



code	size	thread size [inch]	spanner size [mm]
EW-MS-18582	5	1/8	10
EW-MS-18583	7	1/4	13
EW-MS-18585	8	3/8	17
EW-MS-18587	12	1/2	21
EW-MS-18588*	19	3/4	25
EW-MS-18589*	25	1	30

90°elbow, BSP female / male



code	size	thread size [inch]	spanner size [mm]
EW-MS-18542	6	1/8	10
EW-MS-18543	8	1/4	13
EW-MS-18545	11	3/8	17
EW-MS-18547	15	1/2	21
EW-MS-18548	19	3/4	25
EW-MS-18549	25	1	30

Tee, BSP male



code	size	thread size [inch]	spanner size [mm]
EW-MS-18597	5	1/8	10
EW-MS-18596	8	1/4	13
EW-MS-18595	9	3/8	17
EW-MS-18594	12	1/2	21
EW-MS-18593*	19	3/4	25
EW-MS-18592*	25	1	30

Tee, BSP female / male / female



code	size	thread size [inch]	spanner size [mm]
EW-MS-18562	6	1/8	10
EW-MS-18563	8	1/4	13
EW-MS-18565	11	3/8	17
EW-MS-18567	15	1/2	21
EW-MS-18568	19	3/4	25
EW-MS-18569	25	1	30

Tee, BSP female / female / male



code	size	thread size [inch]	spanner size [mm]
EW-MS-18512	6	1/8	10
EW-MS-18513	8	1/4	13
EW-MS-18515	15	3/8	17
EW-MS-18517	19	1/2	21
EW-MS-18518*	25	3/4	25
EW-MS-18519*	30	1	33

Tee, BSP female



code	size	thread size [inch]
EW-MS-185197	8	1/8
EW-MS-185196	11	1/4
EW-MS-185195	15	3/8
EW-MS-185194	19	1/2
EW-MS-185193	25	3/4
EW-MS-185192	30	1

* - without internal cone

INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - EW type

Tee, BSP female



code	thread size [inch]
EW-MS-12135	3/8
EW-MS-12150	1/2

Cross, BSP female



code	thread size [inch]
EW-MS-12134	3/8
EW-MS-12154	1/2

90° elbow, BSP female



code	size	thread size [inch]
EW-MS-185182	6	1/8
EW-MS-185183	8	1/4
EW-MS-185185	15	3/8
EW-MS-185187	19	1/2
EW-MS-185188	25	3/4
EW-MS-185189	30	1

90° elbow with mounting ears, BSP female



code	thread size [inch]	mounting (hole DN) [mm]
EW-MS-12155	3/8	4.5
EW-MS-12156	1/2	4.5
EW-MS-12157	3/4	4.5

Angled air diffuser with mounting ears 5 x BSP female



code	thread size [inch]	mounting (hole DN) [mm]
EW-MS-12159	1/2	5.5

Straight air diffuser with mounting ears 5 x BSP female



code	thread size [inch]	mounting (hole DN) [mm]
EW-MS-12158	1/2	5.5